



## FM3600-410A

### Features

- Faster than competitive units
- Machines recover ALL refrigerants including R-410A\*
- 550 PSI high pressure cut-off, high pressure gauges
- New proprietary high performance compressor
- Small and lightweight for easy operation
- Rugged and reliable
- Evacuation complete shut-off

## FM3600-410A Commercial Recovery Unit

For commercial refrigerant recovery applications, the FM3600-410A can recover vapor at up to two pounds per minute, and can tolerate liquid directly through its compressor. Its large condenser has twice the capacity of other units for fast recovery in the hottest environments. A self-purging valve allows the condenser and tubing to purge without hose changes. The suction and discharge gauges and LCD status display keep the technician informed during each recover step.

SPECIFICATIONS	
Refrigerants	R-410A, R-12, R-134a, R-22, R-500, R502, MP/HP blends
Power Source	115 VAC 50/60 Hz, 230 VAC 50/60 Hz, 100 VAC 50/60 Hz
Compressor	1/2 horsepower high performance, oil-less
Vacuum Rating	13" Hg+
High Pressure Limit	550 PSI
Recovery Rate	.30 - 2.0 lbs./min vapor 4.0 lbs./min. liquid
Auto 80% Tank Shut-Off	Optional
Self Purging System	No hose changes
Weight	35 lbs.
Dimensions	12" x 13" x 7.5"

ORDERING INFORMATION	
PART NO.	DESCRIPTION
03600-410	FM-3600-410A Commercial Recovery System
070020	Carrying Case/Backpack for FM3600-410A
020081	80% Shut-Off Option

\*Not for use with R-11 or R-123



## FM3700

### Features

- Faster than competitive units
- Machines recover most popular refrigerants\*
- 450 PSI high pressure cut-off, high pressure gauges
- New proprietary high performance compressor
- Small and lightweight for easy operation
- Rugged and reliable
- Evacuation complete shut-off

## FM3700 Heavy Duty Commercial Recovery Unit

The FM3700 is simply the most powerful, portable, oil-less refrigerant recovery unit available. The 3700's industrial strength one horsepower, twin piston compressor enables the unit to recover refrigerant vapor at up to four pounds per minute and up to eight pounds per minute liquid directly through the compressor.

SPECIFICATIONS	
Refrigerants	R-12, R-134a, R-22, R-500, R502, MP/HP blends
Power Source	115 VAC 50/60 Hz, 230 VAC 50/60 Hz, 100 VAC 50/60 Hz
Compressor	1 horsepower twin piston, high performance, oil-less
Vacuum Rating	13" Hg+
High Pressure Limit	450 PSI
Recovery Rate	.50 - 4.0 lbs./min vapor, 8.0 lbs./min. liquid
Auto 80% Tank Shut-Off	Optional
Self Purging System	No hose changes
Weight	47 lbs.
Dimensions	12" x 14.25" x 8.75"

ORDERING INFORMATION	
PART NO.	DESCRIPTION
03700	FM-3700 Industrial Recovery System
070030	Carrying Case/Backpack for FM3700
020081	80% Shut-Off Option

\*Not for use with R-11 or R-123